



18 Point Check List

HI-1 Scanner

METH scanner

This is a guide for inspection of buildings when using the ID2 HI-1 Meth Scanner. This guide covers most of the common areas where meth can be found, giving a high degree of confidence that if no meth is detected in **any** of these 18 areas, the home is free of methamphetamine residue. This guide also helps minimize the possibility of a false positive reading, which may occur if non-essential surfaces or substances are checked. For more information on the operation of your ID2 HI-1 Meth Scanner, please consult the operator's manual or contact CDEX Technical Support.

Kitchen

1. Window Frame
2. Stove Top
3. Stove backsplash
4. Exhaust fan(s) (if applicable)
5. Kitchen Sink

Bathroom

1. Countertop
2. Window (if applicable)
3. Spot check tile flooring
4. Exhaust fan(s) if applicable
5. Tub/shower/sink drains

Living/common areas(s)

1. Window frame(s) (don't forget top of sill)
2. Ceiling above sitting area(s) (10' and lower)
3. Tile/Carpet flooring

Bedroom(s)

1. Window frame(s) (don't forget top of sill)
2. Ceiling above sleeping area
3. Spot check wall next to bed

Airflow return vent

1. Check all airflow return vents, fins and filters
2. With forced air heating and cooling systems, check furnace and air conditioners

Inspection Notes: